

*****IMPORTANT NOTICE*****
RE: 80'S SERIES REMOTE STARTERS**

****Affected Models- 1180, 1280, 2280, 3280, 3285, 4280, 4285.**

ISSUE

The system “drops” or will only program one remote.

SYMPTOM

When programming the transmitters the system reacts as if it has programmed all the remotes. After exiting transmitter program mode only one of the remotes will function.

SOLUTION

During the remote programming procedure press the lock button on each remote 2 times.