

## Shock Sensor Programming/Adjustment

### To Enter Shock Sensor Programming

**Method 1** - Press & Release the **LOCK** button 5 times (once every one second). The Siren will chirp 3 times and the park lights will stay on.

**Method 2** - Press & Hold the **LOCK & UNLOCK** buttons for 3 seconds. The siren will chirp 3 times and the park lights will stay on.

While the park lights are on strike the vehicle with the amount of force wanted to trigger the alarm\*. Strike the vehicle the same amount of force 3 times. The siren will chirp each time the system detects impact.

\* Strike the vehicle with the palm of the hand, be careful not to impact the vehicle in an area that may cause damage. The most common location for testing and setting the shock sensor is the A-pillar. The A-pillar is the metal support that runs from the roof of the vehicle to the hood area. Avoid hitting the windshield when programming.

*\*Press **UNLOCK** to exit shock sensor programming.*

## Temporary Shock Sensor Bypass

1. Press and Release the **LOCK** button(to arm system).
2. Press and Release **\*** button (within 3 seconds).  
The system will chirp once to arm and once again to confirm Temporary Shock Sensor Bypass.

The shock sensor will return to normal operation the next time the system is armed.